

OPERATIONAL, TECHNICAL AND LOGISTICAL POLICIES FOR THE BARCELONA WINE WEEK 2025 TRADE SHOW

CONTENTS

1	. HOW TO GET TO THE MONTJUIC VENUE	2
2.D	EADLINE SCHEDULE AND SUMMARY OF IMPORTANT ASPECTS TO CONSIDER	3
	2.1 Deadline Schedule	3
	2.2 Summary of important aspects to consider	
3 C	ENERAL POLICY FOR THE ASSEMBLY, DISMANTLING AND INSTALLATION, AND SERVICE OF STANDS	7
o.c	ENERGIA DE OTTO TO THE ACCELUIDET, DICHART ENGANADING TACIONES THOU, AND CENTRE OF CHARDOMINISTERS	
	3.0 Relevant information for your participation, dates of assembly, celebration and disassembly	
	3.1 Assembly	
	3.2 Assembly project validation process	
	3.2.1 Steps to follow for construction and validation according to stand type	
	3.3 Height policy on stand construction and decoration	
	olo holgha policy on olana conocidentalia accordant	
	3.3.1 Limits for stand assembly and adaptation of exhibition spaces	
	3.3.2 Partition walls	
	3.3.3 Rigging or suspended elements.	
	3.3.4 Covering of columns, height (insetting) and spaces with fire hoses	
	3.3.5 Disabled access.	
	3.3.6 Electrical installations.	
	3.3.7 Water installation.	
	3.3.8 Stand image and transparency	
	3.3.9 Safety easement	17
	3.4 Gas, Installations and Exhaust system	18
	3.5 Machines and devices in operation	18
	3.6 Cleaning and Waste Management during stand assembly and dismantling	18
	3.7 Surveillance of exhibition areas and client assets	19
	3.8 Dismantling	20
1	ACCESS, HALL RESISTANCE AND MANAGEMENT OF GOODS DURING ASSEMBLY, THE TRADE SHOW DAYS AND	
	SMANTLING	
	4.1 Access map to the venue during the ASSEMBLY	
	4.2 Access map to the venue during the TRADE SHOW DAYS	
	4.3 Access map to the venue during the DISMANTLING	24
5.	SPECIAL HEIGHTS IN THE VENUE AND PROBLEMATIC RIGGING POINTS	25
	5.1 Indicative plan of the special heights in the halls which may affect the construction of your stand	25
	5.2 Indicative plan of problematic rigging points	
6.	EVACUATION PLAN	27
7.	FOR MORE TECHNICAL INFORMATION GO TO THE FIRA BARCELONA POLICY	27



1. HOW TO GET TO THE MONTJUÏC VENUE

From the airport:


- By road: 15 kilometres away (C-31 main road)
- Train: R2 Norte commuter train (Renfe), station: Barcelona-Sants
- Airbus: direct connection to the venue
- Bus: TMB municipal bus company No. 46 (stop: Pl. Espanya FGC)
- Metro: Line L9 Sud to the station: Torrassa, and connect with L1 to the station: Espanya

From other parts of the city:

Metro: L1, L3 station: Espanya

Venue address:

Fira de Barcelona, Montjuïc Trade Show Venue. Av. Reina Mª Cristina, s/n 08004 (Barcelona)





2. DEADLINES SCHEDULE AND SUMMARY OF IMPORTANT ASPECTS TO CONSIDER

2.1 Deadlines schedule

DATE ITEM TIME	DEADLINE DEAD	DLINE
Prior assembly		
Deadline to receive the stand plans		
July - December 2024		12 of DECEMBER 2024
December 2024 - January 2025		10 of JANUARY 2025
Contracting of Services through FiraStore, prices with a 30% surcharge		14/01/2025
During assembly		
Start of assembly	08:00h to 20:00h	27/01/2025
Deadline for carpentry works inside the Hall	20:00 h	31/01/2025
Deadline for vehicles to enter the Hall	20:00 h	31/01/2025
Start to decoration and producto placement	08:00 h to 20:00 h	01/02/2025
Delivery stands PACK	16:00 h	01/02/2025
Deadline to decoration and producto placement	08:00 h to 22:00 h	02/02/2025
During celebration		
Last day for product placement with authorisation	07:00 to 08:00 h	03/03/2025
Opening of the Trade Show to exhibitors	08:00 h	03/02/2025
Opening of the Trade Show to visitors	10:00 h	03/02/2025
Goods Restocking	07:00 h to 08:00 h	4-5/02/2025
Closing of the Trade Show to visitors	17:00 h	05/02/2025
Closing of the Trade Show to exhibitors	17:30 h	05/02/2025
During dismantling		
Removal of goods by hand	17:30 h to 22:00 h	05/02/2025
Beginning of the dismantling of the Trade Show	08:00 h to 20:00 h	06/02/2025
End of the dismantling of the Trade Show	20:00 h	08/02/2025



2.2 Summary of important aspects to consider.

From section 3.1, Assembly, on page 8

Assembly schedules:

The assembly schedule from the Monday 27th January to Saturday 1st February, will be all day from 8:00 pm and Sunday 2nd February will be all day from 8:00 pm to 10:00 pm.

IMPORTANT: Entry of vehicles to the Hall to deliver items 2 days before the opening day is strictly forbidden (in other words, after 8:00 PM on Friday 31st January).

After 8:00 pm on Friday 31st January, no carpentry work or any other work that generates debris will be allowed. Only the finishing touches and product layout will be permitted. The Organiser is authorised to apply a penalty of €300 (10% VAT not included) to companies which fail to comply with this rule.

To process valid passes for assembly companies, for the **assembly and breakdown period**, they will have to access the online registration platform as of **22**nd of **December 2024** on https://contractorpass.firabarcelona.com/WEB/J134025/passes

From section 3.2, assembly project validation process, on page 8

IMPORTANT: Your decorator can find this document along with the Technical Policy of Fira Barcelona in the Assembly Area of the show website: https://www.barcelonawineweek.com/en/contractor-area/ as well as information on how to manage the assembly passes.

Assembly companies will have to access the online registration platform as of 22nd of December 2024 on https://contractorpass.firabarcelona.com/WEB/J134025/passes in order to attain the assembly passes for their entire team, valid during the build-up and breakdown stage.

To validate **passes during build-up and breakdown** for assembly companies, they will have to access the online registration platform as of 22nd of December 2024 on https://contractorpass.firabarcelona.com/WEB/J134025/passes

Exhibitors should note that in order to ensure that buyers have a favourable impression of the Trade Show, exhibitors are strictly forbidden from leaving their stands or leaving them unattended or unstocked on **Wednesday** 5th February before the scheduled end of the Show at 5:00 pm except in the event of force majeure. The Organiser may impose a fine of €3,000.

From section 3.2.2, Construction, Stand structure types and Engagement of products and services- FiraStore, on page 11

Modular stands or structures more than 5 metres high. These must have a minimum of three perpendicular support plans over their entire height. Cases in which H>5 m are regarded as complex structures.

Single structures that are greater than 4 metres high. These structures are regarded as singular in totem-type constructions, isolated or corporeal partitions or any structure that doesn't have at least three perpendicular support planes over their entire height. H>4 m and B/H<0.4 (slenderness coefficient: relationship between dimension B and the height of element H

IMPORTANT: The services offered through the Fira Store will have a **30% discount** until **14**th **January**, after which time there will be less on offer and products will be subject to stock availability.

From section 3.3, height policy on stand construction and decoration, on page 13

You will be able to access the 360° view of the hall in which your stand is located through the following web page: https://guestevents.firabarcelona.com/en/enclosure/montjuic/hall-1/ https://guestevents.firabarcelona.com/en/enclosure/montjuic/hall-8/



From section 3.3.3, rigging or suspended elements, on page 14

Any elements which are suspended from the ceilings must comply with the Trade Show's Height Regulations. Lighting trusses may be placed at a height of 5.5 meters on the perimeter line of the stand, provided that they do not contain advertising and the characteristics of the Congress Hall allow it. If you want to use them for advertising, they must be consistent with the proportions indicated in the height regulations.

From section 3.3.4, covering of columns, height (insetting) and spaces with fir hoses, on page 15.

IMPORTANT: It is obligatory that the Design stands include in a visible place to display the assigned numbering that appears in their participation contract, in order to make it easier for visitors to find the stand. The number must be located at a maximum height of 2.20m and a minimum of 1.50m on all sides of the street (letter) where the stand is located.

From section 3.3.6, electrical installation, on page 12

the event that a client has more than one CETAC in use and that any of the adjoining stands to be fed from the same pit does not have the minimum connection guaranteed by the trade show, the organiser may be obliged to require the removal of one of the existing electrical switchboards in order to guarantee the minimum connections for each stand and this may incur extra costs for the exhibitors concerned.

From section 3.3.8, stand image and transparency, on page 17

IMPORTANT: In order to lead to a general effect of spaciousness and so as not to prejudice the other exhibitors, full transparency in the design of all the stands is requested and we also inform you that at least half the length of each façade (50%) must be either glazed or open. If you have any questions, please contact operations.bww@firabarcelona.com

The Organiser is authorised to request the necessary changes in the design of your stand if it impairs the visibility of the other exhibitors and to ensure it complies with the above-mentioned Regulations, even when the project has been previously approved and endorsed by the Organiser. For any questions regarding the Construction Regulations, please contact the operations department at: operations.bww@firabarcelona.com

From section 3.6, cleaning and waste management during stand assembly and dismantling, on page 18

In order to validate the proper waste management during breakdown, either by your own methods or by contracting our supplier, the assembly company must ask the manager of your hall to stamp the WASTE MANAGEMENT FORM, certifying that it has left the space in which the stand in question is located, clean and clear and that no waste has been left in any space within the venue grounds. This stamped form will guarantee that no refuse invoice will be generated. You will find form operational through the Exhibitor Area or on the Trade Show Website (Contractor Area).

From section 3.7, Surveillance of exhibition areas and client assets, on page 19

During the assembly, celebration and disassembly periods, Fira de Barcelona will be in charge of general surveillance. Fira de Barcelona will NOT be responsible for the theft or theft of materials and objects placed in the stands. The surveillance and security of each client's private belongings is the exclusive responsibility of each client.

In the event that a client wishes to have a private security service for their stand or hire the storage service, they can do so through the Fira Store catalog and make the purchase directly on the page https://store.firabarcelona.com/K134025/.



From section 3.8, dismantling, on page 20

Exhibitors should note that in order to ensure that buyers have a favourable impression of the trade show, exhibitors are strictly forbidden from leaving their stands or leaving them unattended or unstocked on **Wednesday** 5th February before the scheduled end of the show at 5:00 pm except in the event of force majeure. The Organiser may impose a fine of €3,000.

On **Wednesday** 5th exhibitors must remove their goods by hand after 5:30 pm and until 10 pm. There will be no vehicle access inside the hall on **Wednesday** 5th February from 5:30 pm to 10 pm, nor may you stand be dismantled. The Thursday 6th February from 8:00 am to 8:00 pm vehicles will be able to enter the hall.

IMPORTANT: remember that if any products require cold storage and they are not going to be taken way on the last day of the trade show (when the goods retrieval period begins), you must engage the electrical power services via the Fira Store https://store.firabarcelona.com/K134025?lang=en to keep your products cool until the date engaged.

From section 4, access, hall resistance and management of goods during assembly, the trade show days and dismantling, on page 21

IMPORTANT: It is absolutely forbidden for vehicle to enter hall 2 two days prior to the opening of the trade show, that is, after 8:00 pm on Friday 31st January.

From section 5.1, special heights in the venue and problematic rigging points, on page 25

Any elements which are suspended from the ceilings must comply with the Trade Show's Height Regulations. Lighting trusses may be placed on the perimeter line of the stand, measuring up to 5.5 meters in height, provided that they do not contain advertising and that the characteristics of the Congress Hall allow it. If you want to use them for advertising, they must be consistent with the proportions indicated in the height regulations. Due to its architectural characteristics, some areas of the trade show venue have a limited number of anchorage points; therefore, to enable rigging points to comply with safety regulations it will be necessary to install Adaptation Structures whose cost shall be borne by the exhibitor or decorator.



3. GENERAL CONDITIONS FOR THE ASSEMBLY, DISMANTLING AND INSTALLATION OF THE STANDS

3.0. Relevant information for your participation, dates of assembly, celebration and disassembly.

Assembly:

- Pack and design stands contracted with Fira de Barcelona.
 - The <u>pack stands</u> will be delivered at 4:00 p.m. on Saturday, 1st February. * If you need special delivery conditions, contact ServiFira.
 - The <u>design stands</u> contracted with Fira de Barcelona (BuildUp) will be delivered on Sunday 2nd February at 10:00 a.m.
- Free design stands

The assembly dates for the free design stands are from 27th January to 1st February from 8:00 a.m. to 8:00 p.m. and 2nd February from 8:00 a.m. to 10:00 p.m. IMPORTANT:

- It is strictly forbidden the entry of vehicles to the Pavilions for the unloading of goods, 2 days before the inauguration, that is, from 8:00 p.m. hours on Friday 31st January.
- From 8:00 p.m. hours on Friday 31st January, carpentry work or any other type that generates debris will not be allowed. Only final finishes and product placement will be allowed. The Organization is entitled to apply a penalty of € 300 (10% VAT not included) to those companies that fail to comply with this rule.

STAGE	Day	Month	Day	Timetable	
Assembly	27	January	L	8	20
	28	January	M	8	20
	29	January	Χ	8	20
	30	January	J	8	20
	31	January	V	8	20
	1	February	S	8	20
	2	February	D	8	22

^{* **}

Celebration:

The dates of celebration are from 3rd to 5th of February with the following schedules:

Schedule of celebration for Exhibitors:

- Monday 3rd and Tuesday 4th from 08:00 a.m. to 8:00 p.m. hours
- Wednesday 5th from 08:00 a.m to 5:30 p.m.

*Exceptional access from <u>7:00 a.m.</u> to <u>8:00 a.m.</u> for merchandise replenishment and product placement. Consult the conditions in section 3 of the operational, technical and logistical regulations of the show.

Schedule of celebration for Visitors:

- Monday 3rd and Tuesday 4th from 10:00 a.m. to 7:00 p.m. hours
 - Wednesday 5th from 10:00 a.m to 5:00 p.m.

Celebration 3 February L 8 20 7:00-8:00	10	
,	TO	19
4 February M 8 20 7:00-8:00	10	19
5 February X 8 17:30 7:00-8:00	10	17

Removed by hand
17:30-22:00

Dismantling:

The dismantling dates are from 6th to 8th of February, with the following schedules:

- The 5th of February from 5:30 p.m. to 10:00 p.m. Goods may only be removed by hand. It is advisable to remove valuable goods during this period.
- From 6th to 8th of February from 8:00 a.m. to 8:00 p.m.

STAGE	Day	Month	Day	Timetable	
Desmontaje	6	February	J	8	20
	7	February	V	8	20
	8	February	S	8	20

^{*} FORBIDDEN the entry of VEHICLES to the Pavilion for the unloading of goods

^{**} CARPENTRY WORK or any other type that generates debris will not be allowed




3.1 Assembly

Assembly begins on Monday 27th January and is completed on Sunday 2nd February.

Assembly schedules:

- The assembly schedule from the Monday 27th October to Saturday 1st of February, will be all day from 8:00 am to 8:00 pm.
- The assembly schedule for Sunday 2nd February will be all day from 8:00 pm to 10:00 pm.

The assembly schedule may commence at 6:00 am. with prior notice given to the Congress Hall manager. The cost of such a time extension shall be paid by the applicant. The schedule for the request for services (electricity, compressed air, etc.) can be checked by calling the SERVIFIRA department by telephone at: +34 93 233 2000.



After 8:00 pm on Friday 31st January, no carpentry work or any other work that generates debris will be allowed. Only the finishing touches and product layout will be permitted. The Organiser is authorised to apply a penalty of €300 (10% VAT not included) to companies which fail to comply with this rule.

These dates and times apply to both the construction and the reception of goods. Exhibitors are requested to plan their product layout well in advance of the date and time indicated.

Any personnel entering the Venue who are not employed by the exhibitor must provide the Customer Services Department with their full name and ID/Passport for issue of their assembly ID passes.

No exhibitor/assembler/decorator with **pending or outstanding debts** to Fira Barcelona and/or Alimentaria Exhibitions, S.L.U., regardless of the Trade Show/Year/Activity the debt relates to, will be allowed to assemble any stand.

To process valid passes for assembly companies, for the **assembly and breakdown period**, they will have to access the online registration platform as of **the 22**nd **of December 2024 on (https://contractorpass.firabarcelona.com/WEB/J134025/passes)**

During the assembly and disassembly periods and for safety reasons, no type of material or work tools may be placed in the hallways that obstruct the passage through them. All materials must remain within the limits of the stand space itself.

In the event that any aisle is effectively obstructed, the Fira de Barcelona Cleaning Services may remove the objects placed in them, without the client having the right to claim damages for said removal. The costs caused by these actions may be passed on to the corresponding client.

3.2 Assembly project validation process.

In order to be able to assemble your stand it is essential that the organisation has validated your project.

The Assembly Permit will be issued following receipt and approval of your proposed stand design by the Operations and Logistics Department of the Organiser, (e-mail: operations.bww@firabarcelona.com and telephone: (+34) 93 233 20 00). The Permit will be sent together with endorsement approving your project.

The Operations and Logistics Department will provide an updated list of the approved stands to the hall manager to allow him/her to begin the assembly of your stand in your allocated space.

In any case where an Assembly Permit has not been issued, the Organiser may stop or make appropriate changes to the assembly of the stand to ensure its compliance with the applicable Trade Show Policies.

Projects that have not been approved must be changed as requested. Once completed, the new design will be sent to the Department of Operations and Logistics for review and approval.

One validation per project will be sent. The Organiser will send the approval and endorsement with the Assembly Permit to the person who submitted the design, either the Exhibitor or the Designer. Without an Assembly Permit construction may not begin in your space.



IMPORTANT: Your decorator can find this document along with the Technical Policy of Fira Barcelona in the Assembly Area of the show website: https://www.barcelonawineweek.com/en/contractor-area/ as well as information on how to manage the assembly passes.

Assembly companies will have to access the online registration platform as of Friday 22nd December 2024 on https://contractorpass.firabarcelona.com/WEB/J134025/passes in order to attain the assembly passes for their entire team, valid during the build-up and breakdown stage.

The construction permit will be denied to any exhibiting company that does not comply with the trade show policies in force regarding the construction of stands and whose projects have not been submitted to the Organiser's Operations and Logistics department for approval.

All stands/constructions must be submitted for approval to the Operations and Logistics Department via this e-mail address: operations.bww@firabarcelona.com and telephone: (+34) 93 233 20 00 stating the following details:

- · Name of the exhibiting company.
- · Congress Hall in which you are located.
- · Number of your stand.
- · If you will a have a Design or a Modular stand.
- · Renders, floors in your stand and heights.
- Name of the company in charge of assembling your stand.

The permits will be made based on the date the space is allocated. Therefore, to find out when it must hand in the project, the exhibitor must take into account the following schedule:

NOTE: If you have contracted your stand with Fira Barcelona you will not have to make any arrangements regarding the sending of notifications or projects for your stand.

	DEADLINE Submission of the project (stands over 3.5 m) stand type notification (stands smaller than 3.5 m)	DELAY FEE
From July to December 2024	12 of DECEMBER 2024	€340 (VAT not included)
From December 2024 to January 2025	10 of JANUARY 2025	€340 (VAT not included)

You may deliver your projects by email to: operations.bww@firabarcelona.com

The Organiser will be authorised to halt the construction of any stand that fails to comply with the trade show policies specified or any project that has not been approved and endorsed by the Operations and Logistics Department. The Organisation may also fine any company that is in breach of the Stands Construction Rules in the amount of €150/m² (plus 10% VAT).

Assembly passes can be requested through the Exhibitor Area or on the Trade Show Website (Contractor Area). To obtain them, you will need:

- To be up to date with payments with Fira Barcelona
- To be up to date with the contracting of electrical power

To validate passes during build-up and breakdown for assembly companies, they will have to access the online registration platform as of Friday 22nd December 2024 (https://contractorpass.firabarcelona.com/WEB/J134025/passes)


Personnel hired by non-Spanish companies must present their passport or National Identity Card if they are EU citizens. The companies contracting the aforementioned workers must undertake to comply with Spanish regulations regarding the prevention of occupational risks.

Exhibitors should note that in order to ensure that buyers have a favourable impression of the Trade Show, exhibitors are strictly forbidden from leaving their stands or leaving them unattended or unstocked on **Wednesday 5th of February** before the scheduled end of the Show at **5:00 pm** except in the event of force majeure. The Organiser may impose a fine of €3,000.




3.2.1. Steps to follow for construction and validation according to stand type.

Α,



В,



C,





3.2.2 Construction, Stand structure types and Engagement of products and services – FiraStore.

The site assigned during the allocation process is made up of the space only, with the construction of a stand being mandatory. The construction of a stand on the exhibition area being leased is considered a basic requirement.

Remember to download the technical data sheet for your stand in the Exhibitor's Area to find out the technical details of your space.

The Organiser is authorised to enforce compliance with the above for companies that have not made arrangements for the fitting out of a stand. Under no circumstances may the adjacent walls of another exhibitor be used.

Wooden flooring is advised, especially for exhibitors whose stand has water and drainage supplies, multiple electrical connection points or is located near lavatories.

In order to avoid incidents during assembly and/or to ensure a quality reception of the services requested, the Organiser may request or advise that wooden floors are installed for the stand, if the circumstances so require. In the event that the exhibitor does not install wooden flooring, despite the Organiser having recommended it, the participating company will not be compensated for any possible incidents arising from water outlets or hydrants.

Structure Types

Fira de Barcelona may authorise the construction of a complex structure in accordance with the regulations established by the event organiser in the sectors where the roof height and the hall structure so permit.

A complex structure will be regarded as any construction which requires the intervention of a competent technician related to the design, calculation or certification of its final strength or if the assessment of a significant risk is required.

1- NON-COMPLEX STRUCTURE.


o Those that do NOT meet any of the following descriptions of a complex structure:


2- COMPLEX STRUCTURE.

A complex structure is understood to be any construction that requires the intervention of a competent technician related to the design, calculation or certification of its final strength, or if a significant risk assessment is required.


Complex structures are classified in the following manner;


Modular stands or structures more than 5 metres high. These must have a minimum of three perpendicular support plans over their entire height. Cases in which H>5 m are regarded as complex structures.








Single structures that are greater than 4 metres high. These structures are regarded as singular in totem-type constructions, isolated or corporeal partitions or any structure that doesn't have at least three perpendicular support planes over their entire height. H>4 m and B/H<0.4 (slenderness coefficient: relationship between dimension B and the height of element H
















- o Double-deck stands accessible to people on the upper floor.
- o Platforms or stages of the same height or greater than 0.50 m accessible to people.
- o Terraces that are accessible by people. ·
- o Constructions in outdoor areas whose surface area is greater than 16 m².
- o Non-approved constructions in areas with a surface area smaller than 16 m².

Authorisation for the construction of any of these structures must be requested from: operations.bww@firabarcelona.com, attaching the following documentation:

Complex structures must comply with the requirements established in the current regulations and, specifically, with the content of the Technical Building Code in all its sections, as well as the basic documents on structural safety (DB SE), fire safety (DB SI) and use and accessibility safety (DB SUA).

Authorisation for the construction of any of these structures must be requested from the Fira de Barcelona Operations Department at the event address, together with the following documentation:

Prior assembly

Project drawn up, signed and endorsed by a competent technical expert (an authorisation affidavit will be accepted in replacement of the endorsement).

The project must include:

- Descriptive report and proof of compliance with current law.
- Structural stability and resistance study that considers:
 - Use overload in accordance with table 3.1 CTE DB SE, type-C use category.
- Internal 0.125 kN/m² wind up to 4 m in height; an internal 0.063 kN/m² wind will be considered from 4 m in height upwards.
- Description of the loads transmitted to the flooring under each support.
- Dimensional drawings of the floor and elevated elements, including details of the handrails and stairs.
- Evacuation and fire detection plan for complex structures with more than 100 m² of surface area
- Risk assessment and preventive measures to be taken into account during the construction assembly and dismantling process.

The assembly of each of these structures will have to be supervised by a competent technical expert authorised by a professional association and he/she will have to issue an assumption of the commission for said purpose (the authorisation affidavit of the competent technician will be accepted).

If all the documentation provided is correct, authorisation will be given for assembly of the stand or structure presented. If any deficiencies were identified, the observed nonconformities shall be indicated in order to request the appropriate corrections from the client or decorator. Assembly of the stand or structure shall not be authorised until the deficiencies have been corrected.

During the assembly

The technical expert will ensure that the assembly of all the complex structures complies with the conditions established in the documentation provided by the exhibitors. Any request for complementary documentation that is required for structures due to their complexity, even if they are not classified as complex structures as such, will be left to Fira de Barcelona's discretion.

Before the opening

Once the construction of the complex structure has been completed, the technical expert will issue the corresponding certificate to endorse the final structural soundness from the corresponding professional association (an authorisation affidavit will be accepted in replacement of the endorsement), which will be delivered to Fira de Barcelona.

In the case of a structure approved by a competent and authorised body, the approval certificate for the structure will be presented together with the assembly and dismantling standards as a substitute for the structural study.

In the case of a construction that is located in outdoor areas, in addition to the tasks mentioned above, it will be necessary to prove that the action of the wind at a speed not exceeding 100 km/h has been taken into account in the calculation of the structure.



At events organised by Fira de Barcelona, and in the case of double-decker stands, these must be designed so that the second floor does not exceed 50% of the total allocated area, and it must be located so as not to be detrimental to the visibility of the stands within their surroundings.

For more information, see the Technical Policy of Fira Barcelona in the Assembly Area https://www.barcelonawineweek.com/en/contractor-area/ or the Exhibitor's Area (AEX).

Engagement of products and services - Fira Store

All services (rigging, water and power connection, wi-fi, cleaning, catering, etc.) and products (fixtures, graphics, decorative elements, etc.) needed to assemble the stand may be engaged or hired in the ecommerce platform, Fira Store:



IMPORTANT: The services offered through the Fira Store will have a **30% discount** until **14**th **of January 2025**, after which time there will be less on offer and products will be subject to stock availability. https://store.firabarcelona.com/K134025?lang=en


3.3 Height policy on stand construction and decoration.

The maximum permissible height is,

- 3.5 meters around the perimeter of the stand.
- 5.5 meters for elements placed 2 meters towards the interior of the stand.

Volumetric example:


Any element that exceeds 3.5 meters in height must be set back into the interior of the stand according to the following proportion rules.



For example: An element with a height of 5.5 meters is 2 meters higher than 3.5 meters, so it must be set back at least 2 meters away from the perimeter of the stand.



IMPORTANT: None of the stands located in Hall 2, affected by the central visitor walkway, may exceed 5 meters in height at any point of its area of influence, with the same applying for stands in the porch area (along the sides of the hall), which may not exceed 4 meters in any point of their area of influence.



We remind you that the maximum height of 5.5 metres will be allowed as long as the infrastructure of the Hall allows it. We therefore advise you to consult **point 4** (Special heights and problematic rigging points), where you will find the areas in the halls where it is not possible to place items measuring 5.5 metres in height. We also recommend that you refer to all the information on this subject included in the Technical Data Sheet of your stand.



3.3.1 Limits for stand assembly and adaptation of exhibition spaces

No construction elements or elements of any other type may be leaned against the walls, columns or other fixed elements of the pavilions, and adequate protection must be used or a safe distance must be kept between the construction materials and the hall parameters. In no circumstance may the stability of any object, assembly or structure in the Fira Barcelona infrastructure be compromised.

All elements must be self supported. Drilling holes, screwing or nailing into the walls, ceilings, floors or columns of the Halls is not allowed. The creation of ditches, anchors or other construction modifications are not allowed inside the pavilions or in the outside areas of the venue.

Exhibition spaces, both inside and outside, should not be covered with paint or glue. The application of mortar to the floor without there being an intermediary element authorised by Fira Barcelona is prohibited; equally, it is prohibited to drive in nails using percussion tools or to paint using spray guns.

Any damage which may be caused by clients or their delegates to the trade show venue, installations, or other infrastructure, will be repaired by the Fira Barcelona and charged to the client.

3.3.2 Partition walls


When your space is adjacent to those of other exhibitors, it will be mandatory to have your own partition up to the maximum permitted height, perimeter of 3.5 meters high and at least 2 meters high (See point 2.3 on height policy).

The rear walls of the partitions between the stands must be duly treated and without any advertising, in compliance with the trade show's height regulations.

Example

I want to advertise, how to do it if I have a neighbor? Using the height and setback regulations, section 2.3

Any element that exceeds 3.5m in height must be removed towards the interior of the stand the same distance (A) with which it exceeds the height.



3.3.3 Rigging or suspended elements

Applying Fira Barcelona's safety and occupational risk prevention regulations, any company wishing to suspend any object (lighting structures, signs, banners, etc.) from the ceiling of any of the Trade Show Venue's Halls must apply to Servifira by completing the form which can be found in the Fira Store at the following link: https://store.firabarcelona.com/K134025?lang=en

Any elements which are suspended from the ceilings must comply with the Trade Show's Height Regulations. Lighting trusses may be placed at a height of 5.5 meters on the perimeter line of the stand, provided that they do not contain advertising and the characteristics of the Congress Hall allow it. If you want to use them for advertising, they must be consistent with the proportions indicated in the height regulations.

The Barcelona Wine Week height policies shall prevail over the Rigging policies in the event that they are different. Due to its architectural characteristics, some areas of the trade show venue have a limited number of anchorage points; therefore, to enable rigging points to comply with safety regulations it will be necessary to install adaptation structures whose cost shall be borne by the Exhibitor or Decorator.



3.3.4. Covering of columns, height (insetting) and spaces with fire hoses.


If the space assigned to the exhibitor contains pillars inside the stand, these may be covered up to the maximum permitted height (5.5 metres), respecting the safety easement.

Columns which are located on the façade of the stand may be covered to the maximum height allowed for the perimeter and the covering placed on the columns must not protrude more than 0.2 m from the said columns. Any columns with fire hydrants and extinguishers and other elements attached to them may be covered, provided that the services are removable for inspection, visible and properly indicated.

Construction or decorative elements of the stands must not protrude into the passageways under any circumstances.

For example:

- Pilar covering
- Setting back according to to height
- Space with column and hose reel



There is an exception to this rule: the positioning of spotlights with arms on the façades of the stand shall be permitted at a minimum height of 2.2 meters and at a maximum distance of 40 cm from the edge of the façade.

All stands whose floor is raised 50 cm or more above ground level, must present the corresponding certificate (Confirmation of Acceptance) signed by a competent technician.

Any stand exceeding 3.5 meters in height at any point must submit a project (floor plan, height and perspective) to the Operations and Logistics Department of the Exhibition at: operations.bww@firabarcelona.com for its supervision and approval.

The deadline for project submission will be based on when your space is allocated. To confirm the required delivery date for your project you must follow the schedule detailed in **point 2** (Deadline schedule) regarding project delivery deadlines.

In the event that, for any reason, the Organiser does not approve your project, it will be essential to resubmit it with the corrections indicated.

IMPORTANT: It is obligatory that the Design stands include in a visible place to display the assigned numbering that appears in their participation contract, in order to make it easier for visitors to find the stand. The number must be located at a maximum height of 2.20m and a minimum of 1.50m on all sides of the street (letter) where the stand is located.

The Organiser shall be authorised to halt the construction of any stand that fails to comply with the trade show policies specified or any project that has not been approved and endorsed by the **Barcelona Wine Week** Operations and Logistics Department.


It may also fine any company that is in breach of the Stand Construction Rules the amount of €150/m² (10% VAT not included).



3.3.5 Disabled Access.

It is obligatory for all the stands which have wooden floors of more than 5 cm in height to include an access ramp with a minimum width of 1 m, which shall not protrude from the stand into the passageways.

As an exception, a portable ramp will be accepted if no ramp is provided for the wooden floor. If the wooden floor is hired from Servifira, it is obligatory to hire a ramp.



3.3.6 Electrical installations.

All installations must be carried out according to the requirements of the Low Voltage Electrotechnical Regulation (REBT) and its complementary technical instructions, by an electrician officially authorised by the Catalonia Government's Department of Industry, with the corresponding electrical installation bulletin completed (official certificate).

It is very important to remember that:


- 1. The work on low-voltage electrical facilities must be performed by authorised low-voltage installers in both the assembly and dismantling phases.
- 2. It is the responsibility of the company performing the dismantling work to check, prior to the start of said work, that there is no voltage in the entire working area of the stand.
- 3. If you have electrical boxes in your assigned space, it must be possible to inspect and gain access to them (See technical data sheet of your space).



IMPORTANT: The trade show organiser guarantees a minimum CETAC industrial electric connection (16 A) for each stand. In the event that a client has more than one CETAC in use and that any of the adjoining stands to be fed from the same pit does not have the minimum connection guaranteed by the trade show, the organiser may be obliged to require the removal of one of the existing electrical switchboards in order to guarantee the minimum connections for each stand and this may incur extra costs for the exhibitors concerned.

Distribution of services according to whether they are in columns or in manholes






Whenever a service chest is shared between more than one stand in one island, it must remain accessible at all times through a hatch).

In order to have a hatch, we recommend a platform of 50mm for electrical cables only, and 100mm if a water connection is planned for any of the neighbouring stands.

If during build up or show any cable gets unplugged for som reason, the chest needs to be accessed by the technical teams



Whenever a service chest is half covered by a division wall or is at the limit of the stand, the area around the chest must remain accessible.



3.3.7 Water installation.

It is recommended that water installations are accompanied with the installation of a technical wooden floor in order to improve the appearance and ensure the safety of visitors to your stand. Please note that all requests for the installation of supplies must be accompanied by a technical plan with the design of the stand so that the pre-installation can be planned correctly.

It is recommended that you request these services well in advance to ensure their availability and correct installation. The service can be engaged through the Fira Store at the following link: https://store.firabarcelona.com/K134025?lang=en.

3.3.8 Stand image and transparency.

The rear walls of the partitions between the stands must be duly treated and without any advertising, in compliance with the trade show's height regulations (see point 3.3.4).

IMPORTANT: In order to lead to a general effect of spaciousness and so as not to prejudice the other exhibitors, full transparency in the design of all the stands is requested and we also inform you that at least half the length of each façade (50%) must be either glazed or open. If you have any questions, please contact operations.bww@firabarcelona.com

The Organiser is authorised to request the necessary changes in the design of your stand if it impairs the visibility of the other exhibitors and to ensure it complies with the above-mentioned Regulations, even when the project has been previously approved and endorsed by the Organiser. For any questions regarding the Construction Regulations, please contact the operations department at: operations.bww@firabarcelona.com

The Organiser shall make considerable efforts to provide the **BARCELONA WINE WEEK** trade show with an image in accordance with the levels of quality and professionalism of the trade show. In order to preserve these parameters, we ask exhibitors to carefully review their construction projects, paying special attention to the aesthetic aspects that contribute to enhancing **BARCELONA WINE WEEK** overall image.

3.3.9 Safety easement.

The location of signposts, fire-fighting equipment, alarms, emergency exits, service boxes, access to columns with air-conditioning installations and rights of way shall be respected at all times and shall be obligatory, ensuring access to any of them is always possible. We recommend that you read the key that appears in the Technical File referring to the allocated space, which can be consulted in the Exhibitor's Area.

Stands with accesses over 15 meters in width must install their own fire extinguishers. These must be correctly mounted near the escape routes and installed in a visible location at least every 15 meters. The installation of fire extinguishers is mandatory in any stand which contains two floors. The extinguishers can be rented through the Fira Store at the following link: https://store.firabarcelona.com/K134025?lang=en





3.4 Gas, Installations and Exhaust system.

The discharge of vapours, flammable or toxic gases that may be harmful to health or bothersome to the public or other clients at the event is not permitted.

Toxic gases and vapours generated by combustion must be vented to an external area through ducts that are suited to this purpose. To this effect, technical feasibility studies for the location and attachment of said ducts must be requested from the Operations and Logistics Department operations.bww@firabarcelona.com.

If the project is technically feasible, the client shall be responsible for the costs of the execution of the installation. The deadline for said request is 22nd of December 2024.

In any case, the provisions in the technical regulation for the distribution and use of gaseous fuels RD 919/2006 and its complementary technical instructions IG01 to 11 must be complied with.

If the gases or vapours are not harmful to the health (steam or vapours from the cooking of food, for example) but give off an odour that may be unpleasant to the other clients, a **hood with suitable filters must be installed to absorb said odours**. The exhibitor must meet compliance with said standards, as well as the consequences derived from any non-compliance.

If the use of domestic gas is necessary, the installation and supply of gas by an authorised company must be legalised for this purpose by delivering the relevant bulletin.

The office closest to Fira Barcelona is Repsol Butano, Agencia TOSSA, Ronda Sant Antoni, 52 (or the one operating at any given time).

The installations must adhere to current regulations.

In both cases, the corresponding certificates must be submitted to the Operations and Logistics Department operations.bww@firabarcelona.com

The deadline for submitting this documentation is 22nd of December 2024

3.5 Machines and devices in operation.

The exhibitor shall fit the installations that shall be operated during the event with all the necessary protection devices to operate them, as well as to prevent accidents, which are required by the technical regulations defined for such installations.

If the machinery or certain parts are to be shown to visitors whilst being operated, the normal protection can be replaced by a covering of organic glass or similar transparent material. If the machines are switched off and they are for display purposes only, the protective devices may be removed.

In the event of any serious breaches of this rule, and if the operation of the machinery could pose a danger to people, the Event Management is authorised to demand them to be switched off.

If there is a breach in these terms and conditions, the liability for any accident occurring will fall exclusively on the exhibitor, who must have taken out a Civil Responsibility Insurance policy for damages to third parties, persons or objects for an unlimited amount.

3.6 Cleaning and Waste Management during stand assembly and dismantling.

The company responsible for the construction and/or decoration of the stand will be responsible for removing the waste generated at the end of each day during both the assembly and disassembly periods. The fire prevention policy prohibits the accumulation of waste in the stands and their storage areas, as well as in the aisles and shared spaces.

The work material must be within the space assigned to the exhibitor and it is strictly forbidden to place any waste or any other element blocking the aisles.

Exhibitors/contractors may engage the service for the removal of waste and the storage of materials/packaging through the Fira Store online services catalogue at the following link: https://store.firabarcelona.com/K134025?lang=en or at the Customer Services desk during build up, the trade show days, and the breakdown period.

The management of the removal of the generated waste may be performed by your own methods or by engaging the service through Fira Store online catalogue. Other waste management companies unrelated to Fira de Barcelona must be accredited in order to offer their services at the venue and must pay the relevant fees to gain access. General waste bins will not be provided in the aisle, as they have to be hired. The 20/30 m3 waste boxes cannot remain overnight within the trade show venue.



In order to validate the proper waste management during breakdown, either by your own methods or by contracting our supplier, the assembly company must ask the manager of your hall to stamp the WASTE MANAGEMENT FORM, certifying that it has left the space in which the stand in question is located, clean and clear and that no waste has been left in any space within the venue grounds. This stamped form will guarantee that no refuse invoice will be generated. You will find form operational through the Exhibitor Area or on the Trade Show Website (Contractor Area).

Cooperation in the carpeting of aisles

The period for carpeting the aisles inside the pavilions coincides with the assembly, so we request your full cooperation and for you to heed the pavilion manager's requests/indications, leaving the aisles adjoining your stand free of materials and waste on the required dates.

3.7 Surveillance of exhibition areas and client assets

During the assembly, celebration and disassembly periods, Fira de Barcelona will be in charge of general surveillance, as well as general and preventive security in matters of order and safety against fires or emergencies of any kind.

In no case is it a security directed and focused on the goods on display, nor on the private goods of each client. Consequently, Fira de Barcelona is not responsible for private property owned by clients or their employees. Fira de Barcelona will also not be responsible for the theft or theft of materials and objects placed in the stands or in any other space in the venue, nor for any damage that they may suffer during the assembly, celebration and disassembly periods.

Entry and exit of objects and merchandise

All merchandise addressed to Fira de Barcelona must be perfectly identified (venue, pavilion, stand number and exhibiting company) and must be received by the client themselves. The arrival of merchandise to the pavilions that make up the fairgrounds must be coordinated so that the people authorized by the client receive the material at the unloading location. Under no circumstances will Fira de Barcelona be responsible for the receipt of said merchandise. Responsibility for display materials corresponds solely and exclusively to the client and authorized installer.

Therefore, the surveillance and security of each client's private belongings is the exclusive responsibility of each client. However, Fira de Barcelona may provide the necessary support for the resolution or processing of the corresponding complaint before the authorities.

In the event that a client wishes to have a private security service for their stand or hire the storage service, they can do so through the Fira Store catalog and make the purchase directly on the page https://store.firabarcelona.com/K134025/.

If, on the other hand, the client wishes to contract the surveillance service with another security company outside of Fira de Barcelona, they must send, at least 48 hours in advance, to the Security and Mobility management of Fira de Barcelona, the "Private surveillance at stands" form duly completed, which contains the regulations and conditions for the provision of this service.

During the assembly, celebration and disassembly periods, Fira de Barcelona will be in charge of general surveillance.

Fira de Barcelona will NOT be responsible for the theft or theft of materials and objects placed in the stands. The surveillance and security of each client's private belongings is the exclusive responsibility of each client.

In the event that a client wishes to have a private security service for their stand or hire the storage service, they can do so through the Fira Store catalog and make the purchase directly on the page https://store.firabarcelona.com/K134025/.



3.8 Dismantling

The Trade Show will close its doors to the professional public at 5:00 pm on Wednesday 5th of February.

Exhibitors should note that in order to ensure that buyers have a favorable impression of the trade show, exhibitors are strictly forbidden from leaving their stands or leaving them unattended or unstocked on **Wednesday 5**th of **February** before the scheduled end of the show at **5:00 pm** except in the event of force majeure. The Organiser may impose a fine of €3,000.

On **Wednesday 5th of February** exhibitors must remove their goods by hand after 5:30 pm and until 10 pm. There will be no vehicle access inside Hall on **Wednesday 5th of February from 5:30** pm to 10 pm, nor may you stand be dismantled. From **Thursday 6th of February from 8:00** pm, vehicles will be able to enter the halls.

IMPORTANT: remember that if any products require cold storage and they are not going to be taken way on the last day of the trade show (when the goods retrieval period begins), you must engage the electrical power services via the Fira Store https://store.firabarcelona.com/K134025?lang=en to keep your products cool until the date engaged.

Plan and organise the removal of the products from your stand well in advance, ensuring that your belongings are supervised at all times. Please note that during this time period, the removal of goods and the visitors leaving the event will coincide at the access points. Stands must be completely empty by 10:00 pm on Saturday 8th of February. In the event that the goods cannot be removed before that time, the exhibitor must ensure that they are kept in a safe place to prevent possible theft.

Although there is security in place, the Organiser shall not be held responsible for any theft or pilfering that may occur.

The work on low-voltage electrical facilities must be performed by authorised low-voltage installers in both the assembly and dismantling phases.

It is the responsibility of the company performing the dismantling work to check, prior to the start of said work, that there is no voltage in the entire working area of the stand.

On the following day, Thursday 6th of February, the dismantling of the Fair will begin from 8 am until 8 pm and heavy vehicles can then access the interior of hall.

We would like to remind you that any decoration / vinyl posters, contracted from companies other than Fira Barcelona's official suppliers and which have been used in the structure of the stand, must be removed at the end of the Fair. Otherwise, the exhibitor will be sent an invoice for the removal of the waste.

The dismantling of the Trade Show will be carried out during the 4 days following the trade show days and must be fully completed by **Saturday 8**th of **February**. Fira de Barcelona reserves the right to dismantle a stand or to move the existing goods at the exhibitor's expense if this has not been completed by the deadline. Similarly, the Organiser may change the dismantling times if considers it necessary.

IMPORTANT: For any questions regarding the general conditions for the assembly, dismantling and installation of stands, please consult the Technical Policy of Fira Barcelona (Montjuic Venue) that you will find in the Exhibitor's Area (AEX) and the Assembly Area https://contractorpass.firabarcelona.com/WEB/J134025/passes



4 ACCESS, HALL RESISTANCE AND MANAGEMENT OF GOODS DURING ASSEMBLY, THE TRADE SHOW DAYS AND DISMANTLING.



Exhibitors are advised to plan for the arrival of their goods at the trade show venue well in advance.

IMPORTANT: It is absolutely forbidden for vehicle to enter hall two days prior to the opening of the trade show, that is, after 8:00 pm on Friday, 31st of January 2025.

RESA EXPO LOGISTICS, our logistics operator, offers the following services;

IN THE VENUE

- Loading/Unloading of vehicles
- Rental of lifting machinery
- Storage of goods prior, during and after the event in the general warehouse.
- Storage of empty packaging during the event in the general warehouse.
- Rental of individual storage containers

BEFORE / AFTER ARRIVAL AT THE VENUE

- Domestic and international transport (courier, ground/air/sea freight)
- Customs procedures

Incoming goods

The participating companies must be responsible for receiving their own goods, as well as storing them. In any case, it is recommended that all goods be clearly labelled (Venue, Hall, Stand No. and Exhibiting Company). Exhibiting companies are requested not to send in their goods using the Organiser itself as the addressee.

Goods storage

The official merchandise handling goods company, RESA EXPO LOGISTICS, offers reception and delivery or unloading services for your products to the stand as well as storage of goods.

Empty packaging

Halls must be completely cleared of packaging 24 hours before the trade show starts. In the event that packaging remains on site, the Organiser may order its removal at the exhibitor's expense. The Organiser shall not be held liable for packaging material which has not been removed in good time.

Goods restocking during the trade show days

Exhibiting companies which need to replenish goods during the trade show days must fill in the Goods Restocking form that can be found in the Exhibitor's Area.

The goods restocking schedule is from 7:00 to 8:00 am, see point 2 (Deadlines Schedule), on 3, 4 and 5 of February.

Onsite logistics services (unloading trucks, rental of machinery and personnel, storage of packaging and merchandise during the event):

Email: logistics@rxl.es Phone: +34 93 2642440

Shipping services (shipments via warehouse, transport & customs);

Email: shipping@resaexpo.com

Phone: +34 93 2334110



4.1. Access map to the venue during ASSEMBLY.

- * From Monday 27th of January to Saturday 1st of February from 8:00 am to 8:00 pm
- * The Sunday 2nd of February from 8:00 am to 10:00 pm

IMPORTANT: Entry of vehicles to the Hall to deliver items 2 days before the opening day is strictly forbidden (in other words, after 8:00 PM on Friday 31st of January).

PLÀNOL DEL RECINTE / MAPA DEL RENCINTO / VENUE MAP



★ Accés carrer de Mèxic obert fins les 21:30h Acceso calle de Mèxic abierta hasta las 21:30h Mèxic Street access open until 9:30 p.m



Accéss de vehícles per càrrega i descàrrega Acceso de vehículos para carga y descarga Vehicles accesss for loading and unloading



Cap de palau Jefe de palacio Hall Manager



Dispensario Dispensary



Parquing exclusiu Expositors.

Parking exclusivo Expositores.

Exclusive parking for Exhibitors



Pàrquing públic Parking público Public parking



CIS - Oficines atenció expositor CIS - Oficinas atención expositor CIS - Exhibitor service offices

Resistencia Palau Resistencia Palacio Hall floor load

5,000Kg/m²



4.2. Access map to the venue during the TRADE SHOW DAYS.

- Last minute product placement on 3rd of February from 7:00 am to 8:00 am
- Goods restocking on 4th and 5th November from 7:00 am to 8:00 am

PLÀNOL DEL RECINTE / MAPA DEL RENCINTO / VENUE MAP







Dispensari

Dispensario

Dispensary





CIS - Oficines atenció expositor

CIS - Oficinas atención expositor

CIS - Exhibitor service offices





- 4.3. Access map to the venue during DISMANTLING.
 - * The 5th of February from 5:30 pm to 10 pm
 - * From the 6th to 8th of February from 8:00 am to 8:00 pm

PLÀNOL DEL RECINTE / MAPA DEL RENCINTO / VENUE MAP



★ Accés carrer de Mèxic obert fins les 21:30h Acceso calle de Mèxic abierta hasta las 21:30h Mèxic Street access open until 9:30 p.m



Accéss de vehícles per càrrega i descàrrega Acceso de vehículos para carga y descarga Vehicles accesss for

loading and unloading



Cap de palau Jefe de palacio Hall Manager



Dispensario Dispensary



Parquing exclusive Expositors.

Parking exclusive Expositores.

Exclusive parking for Exhibitors



Pàrquing públic Parking público Public parking



CIS - Oficines atenció expositor

CIS - Oficinas atención expositor

CIS - Exhibitor service offices




5,000Kg/m²




5 SPECIAL HEIGHTS IN THE VENUE AND PROBLEMATIC RIGGING POINTS.

5.1 Indicative plan of the special heights in the halls which may affect the construction of your stand.

If you have any questions about the heights where your space is located, you can contact the Organiser's Operations and Logistics Department by telephone, at: +34 93 233 20 00










5.2 Indicative plan of problematic rigging points.

If you have any questions about the rigging, you can contact at rigging.montjuic@firabarcelona.com or by phone on +34 930 04 24 24

Rigging points will always be placed according to the Gastronomic Forum Barcelona 2023 height regulations.

NOTE: The Organiser reserves the right to set up adaptation structures in other areas which are not indicated below, the cost of which will be borne by the exhibitor.















6. EVACUATION PLAN







7. POLICIES OF FIRA BARCELONA

For any questions regarding the Policy, visit this link.

https://media.firabcn.es/content/guest%20Events/Regulations/Fira Barcelona Technical Regulations ENG web.pdf